

OTHER **IMPORTANT** INFO...

Always buckle your seat belt.

Practice good driving habits, which will help keep your tires in good condition.

- Obey posted speed limits.
- Avoid fast starts, stops, and turns.
- Avoid potholes and other objects on the road.
- Do not run over curbs or hit your tires against the curb when parking.
- Do not overload your vehicle. Check your vehicle's tire information in the owner's manual for the maximum recommended load for your vehicle.



Tire Pressure Monitoring System (TPMS)

Vehicles equipped with Tire Pressure Monitoring Systems (TPMS) can help motorists detect loss of inflation pressure. Federal regulations require TPMS to warn drivers when tires are 25% under inflated.

For many vehicles this warning may be too late to prevent damage caused by under inflation. TPMS units are NOT a replacement for monthly tire pressure checks with a gauge.

Nitrogen

Nitrogen gas can be safely used in place of compressed air to inflate tires. Nitrogen may aid in tire pressure retention as it does not seep through a tire as quickly as compressed air. Other sources of potential air loss such as punctures, damage or a faulty valve will not be slowed by nitrogen inflation. Whether tires are inflated with compressed air or nitrogen, tire pressure **MUST** be checked every month to ensure proper tire inflation.

Proper tire care helps the environment.

Under inflated tires waste fuel. Properly inflated tires help promote better fuel economy. Additionally, regular care helps tires get the most potential wear so they don't need to be replaced as often.

HOW TO TAKE CARE OF YOUR **TIRES**

Proper tire care and safety is simple and easy. The Rubber Manufacturers Association (RMA) recommends getting in the habit of taking five minutes every month to check your tires, including the spare.

If you think you may have a tire problem or are unsure of the condition of your tires, consult a tire dealer as soon as possible.

ABOUT THE **RUBBER MANUFACTURERS ASSOCIATION**

Founded in 1915, the Rubber Manufacturers Association is the national trade association of the rubber industry. The association is headquartered in Washington, DC and its membership includes companies that manufacture tires and other rubber products.

1400 K Street, NW
Washington, DC, 20005
202/682-4800
fax 202/682-4854
www.betiresmart.org

RMA TIRE MANUFACTURER MEMBERS:

Bridgestone Americas
Continental Tire North America, Inc.
Cooper Tire and Rubber Company
Goodyear Tire and Rubber Company
Michelin North America, Inc.
Pirelli Tire North America
Toyo Tire Holdings of Americas Inc.
Yokohama Tire Corporation

The "Be Tire Smart" program is supported by AAA.



**be tire
smart**
**play your
PART**[®]
PRESSURE • ALIGNMENT • ROTATION • TREAD


A consumer education program of the



RUBBER
manufacturers
association

PRESSURE

It's important to have the proper inflation pressure in your tires, as under inflation can lead to tire failure. The "right amount" of inflation for your tires is specified by the vehicle manufacturer and is shown on either the vehicle door edge, door post, glove box door or fuel door. It is also listed in the owner's manual.



Look for this information in your vehicle:

TIRE AND LOADING INFORMATION			
SEATING CAPACITY		TOTAL 5, FRONT 2, REAR 3	
The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs.*			
TIRE	SIZE	COLD TIRE PRESSURE	SEE OWNER'S MANUAL FOR ADDITIONAL INFORMATION
FRONT	P195/70R14	200KPA, 29PSI	
REAR	P195/70R14	200KPA, 29PSI	
SPARE	T125/70D15	420KPA, 60PSI	

- Check pressure at least once a month and before long trips.
- When you check the inflation pressure, make sure the tires are cool — meaning they are not hot from driving even a mile. (NOTE: If you have to drive a distance to get air, check and record the tire pressure first and add the appropriate inflation pressure when you get to the pump. It is normal for tires to heat up and the inflation pressure inside to increase as you drive. Never "bleed" or reduce inflation pressure when tires are hot.)
- Remember to check the spare. (NOTE: Some spare tires require higher inflation pressure.)
- Visually inspect the tires to make sure there are no nails or other objects embedded that could poke a hole in the tire and cause an air leak. Check the sidewalls to make sure there are no gouges, cuts, bulges or other irregularities.



MAINTAIN CORRECT PRESSURE

Under inflation or overloading creates excessive stress and heat, and can lead to tire failure. This could result in vehicle damage and/or serious injury or death.

An over inflated tire can cause uneven wear in the center of the tread. Over inflation also can make the tire more susceptible to road hazard damage and pose vehicle handling issues.

ALIGNMENT

Misalignment of wheels in the front or rear can cause uneven and rapid treadwear and should be corrected by a tire dealer. Front-wheel-drive vehicles, and those with independent rear suspension, require alignment of all four wheels. Have your alignment checked periodically as specified by the vehicle owner's manual or whenever you have an indication of trouble such as "pulling."

Also have your tire balance checked periodically. An unbalanced tire and wheel assembly may result in irregular wear or vibration.

ROTATION

Sometimes irregular tire wear can be corrected by rotating your tires. Consult your vehicle owner's manual, the tire manufacturer or your tire dealer for the appropriate rotation pattern for your vehicle. (NOTE: If your tires show uneven wear, ask your tire dealer to check for and correct any misalignment, imbalance or other mechanical problem involved before rotation.)

Before rotating your tires, always refer to your vehicle owner's manual for rotation recommendations. If no rotation period is specified, tires should be rotated approximately every 5,000–8,000 miles. (NOTE: After rotation, make sure inflation pressure is set to the vehicle manufacturer's specification.)

TREAD

Tires must be replaced when the tread is worn down to 2/32 of an inch. Traction, particularly in bad weather, and resistance to hydroplaning is reduced as tires wear. An easy test:

place a penny into a tread groove. If part of Lincoln's head is covered by the tread, you're driving with the proper amount of tread. If you can see all of his head, you should buy a new tire.



Built-in treadwear indicators, or "wear bars," which look like narrow strips of smooth rubber across the tread will appear on the tire when the tread is worn down to 2/32 of an inch. When you see these "wear bars," the tire is worn out and should be replaced.

Visually check your tires for signs of uneven wear. You may have irregular tread wear if there are high and low areas or unusually smooth areas. Consult your tire dealer as soon as possible.



TIRE CARE FACTS

- ✓ 27% of passenger cars and 32% of pickup trucks, SUV's and minivans have at least one significant under inflated tire.*
- ✓ 9% of tires on the road are bald.*
- ✓ A tire can lose as much as 50% of its inflation pressure and not appear to be flat.
- ✓ Inflation pressure in a tire goes up (in warm weather) or down (in cold weather) 1-2 pounds for every 10 degrees of temperature change.

* Source: National Highway Traffic Safety Administration